

SYNCHRONIZATION

Performed when the earphones/micro are disconnected



Holding the button  bring the transmitter to the receiver



When synchronization is completed, the backlight tuns on

THE SIGN LEVEL




GREEN
There is signal




RED
The connection was lost

MICROPHONE MUTE



To switch off hold the button  for 1/2 seconds until **RED** is lit up



To switch on hold the button  for 1/2 seconds until **RED** is lit up

SYNCHRONIZATION



To switch on the device, connect the arphone/microphone to the receiver/trasmmitter



To switch off the device, remove the earphone/microphone

THE SIGN LEVEL



To switch ON hold on buttons  at the same moment  for 3/5 seconds until the green **LED** is lit up



To switch OFF hold on buttons  at the same moment  for 3/5 seconds until the **LED** turns off

MICROPHONE MUTE



Connect the charge to the device. When the device is fully charged the green **LED** will be lit up



To charge several devices at the same time, use special equipment